

## 54–575 Removal and installation of switch on clutch pedal with manual transmission

---


### Removal

---

1 Remove cover under instrument panel on driver's side.

2 Pull harness from switch (arrow).

3 Loosen switch (arrow) and remove.



### Installation

---

4 Installation begins in reverse order.

5 Perform function test on road.