



Coding plug (R 29) Remove (54–577)
 Ohmmeter Connect (refer to table)
 Resistance values Check (refer to table), replace coding plug (R 29) if values are deviating.

- a Production date
- b Part number
- c Designation of jack

Test table – resistance values

Part number	Connection ohmmeter on jack designation						
	A–D	B–E	D–C	D–H	E–D	E–F	E–G
005 545 07 32	∞	1470–1530 k Ω	0.01–15 Ω	3.21–3.27 k Ω	∞	26.2–27.2 k Ω	501–521 k Ω
005 545 08 32	∞	1470–1530 k Ω	0.01–15 Ω	1.18–2.02 k Ω	∞	25.2–27.2 k Ω	501–521 k Ω

Conventional tool

Multimeter	SUN	DMM–5
------------	-----	-------