

68–430 Removal and installation of headlining on Coupé top

Removal

- 1 Remove coupe roof and place in inverted condition on a pertinent bench.
- 2 Remove lateral molding strip on coupe roof and center top (68–425).
- 3 Remove weather strip on coupe roof (68–570).
- 4 Remove seal and sealing strip on coupe roof front.
- 5 Remove lock on coupe roof top (77–420).
- 6 Loosen headlining on outer edges of roof.
- 7 Bend up sheet metal clips on both struts.
- 8 Lift off headlining.

Installation

- 9 For installation proceed vice versa.

Note: For gluing headlining use MB-universal glue, part No. 000 989 92 71 only.