

88–110 Removal and installation of panelling between front fender

Removal

- 1** Remove four screws at bottom on connection lower half of fender and air grille.
- 2** Remove screws from fender connection.
- 3** Remove lower half of fender.

Installation

- 4** For installation proceed vice versa.