

## 68–458 Removal and installation of hat rack and tray for first aid kit

---

### Hat Rack

---

- 1 Remove rear seat and rear backrest (91–170).
- 2 Remove partition between fuel tank and trunk compartment.
- 3 Remove the 3 nuts on hat rack from trunk compartment end.
- 4 Lift out hat rack.
- 5 For installation proceed vice versa.

### Tray for First Aid Kit

---

- 1 Push tray out of rear wall sheet metal with a plastic wedge.

The hat rack is **not** removed for this purpose.